

Short Range Target Support Stand Instructions

Shooters,

If you'd like your own target frames, here's how and it only takes three 8' 2x2s to construct two frames.

Please make your frames to our drawing dimensions - ESPECIALLY the overall width - EXACTLY 24 inches. Even with good construction of the frame, 2x2 dimensional lumber is not very consistent and trimming on the bottom of the legs may be require to get them to fit into the frame supports.

For the backer, you can use cardboard or corrugated plastic (like we do at the range). You can buy 24" x 18" corrugated plastic at Home Depot, Lowe's or most any hardware store. Please don't use a backer larger than 24" x 24".

To protect the railroad ties, mounting brackets and most importantly - to KEEP ALL your shots into the berms ---- Please don't place targets lower than 24" below the top of the target frame.

Shoot Straight & Be Safe,

-Camp Fickes Board



